



**NOTES:**

1. FULL LENGTH INSULATING SLEEVES REQUIRED AT ALL THRU-FLANGE BOLTS OR STUDS. HALF LENGTH SLEEVES REQUIRED AT THREADED BOLT HOLES AT VALVE BONNET AND BASE.
2. NO TEST STATION REQUIRED ON BLOW-OFF INSULATORS.

REVISION	BY	APPR	DATE

PARAG KALARIA R.C.E. 83927 DATE

**BURIED INSULATING FLANGE**

STD. DWG. NO.  
**CP-1**